



ASSEMBLE GROMMET AROUND  
DRIVE CABLE AND PLUG INTO  
DECK HOLE

E3-03814A-01