


For Husqvarna Parts Call 606-678-9623 or 606-561-4983



SERVICE		15
---------	--	----

122HBV



1.1992

Spare parts

Pièces détachées

530 06 79-02

PARTS LIST NO.
530-067902 - 7/1/91

PAGE NO.
1


REPLACES
530-067902-6/13/91

HUSQVARNA PARTS LIST

MODEL:
122 HB

Note: Illustrations may differ from actual models due to design changes

SICHER IST DAS:
DAS ORIGINAL




Gasket Kit

Spark Arrestor Kit

Carb. Repair Kit

Carb. Gasket Kit



PARTS LIST NO. 530-067902 - 7/1/91		HUSQVARNA PARTS LIST	MODEL: 122 HB
PAGE NO. 2	REPLACES 530-067902-6/13/91	Note: Illustrations may differ from actual models due to design changes	

Key No.	Part No.	Description	Key No.	Part No.	Description
1	530-015635	Screw	64	530-015918	Screw
2	530-029708	Air Filter Cover	65	530-029603	Isolator
3	530-029611	Air Filter	66	530-029613	Spring
4	530-029615	Handle Cover	67	530-029601	Insulator
5	530-029614	Handle	68	530-015239	Screw
6	530-029608	Handle Isolator	69	530-015872	Screw
7	530-015887	Screw	70	530-029433	Baffle
8	530-015852	Choke Spacer	71	530-039139	Flywheel
9	530-015254	Wave Washer	72	530-015149	Washer
10	530-029480	Choke Shutter	73	530-626605	Nut
11	530-029485	Throttle Wire	74	530-029432	Blower Housing (Upper)
12	530-029481	Choke Mtg. Plate	75	530-094865	Impeller
13	530-029486	Retainer	76	530-014265	Blower Housing (Lower)
14	530-015147	Wave Washer (Knob)	77	530-069271	Blower Tube Kit
15	530-029707	Air Box	78	530-029575	Roller
16	530-035290	Carburetor (WA-207A)	79	530-027523	Retainer
17	530-019164	Carburetor Gasket	80	530-094867	Pulley Housing
18	530-029484	Throttle Knob	81	530-015851	Roll Pin
19	530-015880	Screw	82	530-015772	Screw
20	530-029600	Button	83	530-029448	Pinion
21	530-029607	Spring	84	530-029449	Drag Element
22	530-029709	Shroud	85	530-015882	Screw
23	530-029434	Spring	86	530-069306	Starter Pulley
24	530-015879	Screw	87	530-029395	Starter Spring
25	530-015876	Screw	88	530-027569	Starter Handle
26	530-019154	Gasket	89	530-069232	Rope Kit
27	530-027593	Reed Valve	90	530-015886	Screw
28	530-029781	Reed Stop	91	530-069302	Gasket Kit
29	530-015241	Screw	92	530-069348	Spark Arrestor Kit
30	530-029597	Heat Shield	93	530-035014	*+Metering Diaphragm
31	530-015805	Screw	94	530-035151	*+Metering Diaphragm Gasket
32	530-069293	Muffler	95	530-035212	Mixture Needle
33	530-015771	Screw	96	530-035214	Mixture Needle Spring
34	530-029227	Spark Arrestor Screen	97	530-035166	*+Fuel Pump Diaphragm
35	530-029228	Spark Arrestor Clamp	98	530-035164	*+Fuel Pump Gasket
36	530-029116	Muffler Spring	99	530-035203	Idle Speed Screw
37	530-015126	Key	100	530-035208	Idle Speed Spring
38	530-010945	Crankshaft Ass'y.	101	530-035028	* Metering Lever Pin
39	530-015788	Spacer	102	530-035031	* Metering Lever
40	530-032103	Inner Bearing	103	530-035188	* Metering Lever Spring
41	530-015787	Ring	104	530-035106	* Inlet Needle Valve
42	530-019158	Crankshaft Seal	105	530-035178	* Fuel Inlet Screen
43	530-032102	Outer Bearing	106	530-035260	Carb. Kwik Repair Kit (* Indicates Contents)
44	530-015789	Retaining Ring			
45	530-014004	Crankcase/Crankshaft Ass'y.	107	530-035219	Carb. Gasket/Diaphragm Kit (* + Indicates Contents)
46	530-010897	Fuel Pick-Up Ass'y.			
47	530-069247	Fuel Line Kit	108	530-035211	*+Circuit Plate Gasket
48	530-029602	Foam	109	530-035217	Mixture Needle Washer
49	530-010807	Fuel Cap	110	530-035218	*+O" Ring Mixture
50	530-014267	Fuel Tank Ass'y.	111	530-035016	Metering Lever Pin Screw
51	530-030075	Spark Plug			
52	530-012244	Cylinder			
53	530-027525	Spacer			
54	530-029606	Leadwire Switch			
55	530-015776	Screw	Not Shown		
56	530-039137	Ignition Module		530-067900	Operator Manual
57	530-019178	Gasket		530-061355	Carton
58	530-026413	Piston Ring		530-029714	Instruction Decal (ENG)
59	530-015162	Retainer		530-029715	Instruction Decal (FR)
60	530-014005	Piston Rod			
61	530-069274	Piston Kit (Incl. 58, 59 & Pin)			
62	530-015775	Screw			
63	530-014016	Crankcase Ass'y.			