


For Husqvarna Parts Call 606-678-9623 or 606-561-4983



SERVICE



13

I0400009

IPL, 123 C, L, LD, 2004-01, 106 31 33-61


**123 C**  
**123 L**  
**123 LD**

**Spare parts**  
**Ersatzteile**  
**Pièces détachées**  
**Reserve onderdelen**  
**Repuestos**  
**Reservdelar**


106 31 33-61

**A** 123C

503 79 56-01 537 29 47-05




**B** \*compl 537 34 25-01 123L



**B**


\*compl 537 19 92-02 123LD



**C**


123L

503 79 56-01 537 29 47-04






**G**




**H**

\*\*compl 503 87 33-02  
 \*compl 503 85 28-01




**J**

\*compl 537 06 86-04




**K**

\*compl 503 97 75-01



**L**


\*\*\*compl 537 03 20-06




**M**

\*compl 537 04 11-02


\*\*compl 537 28 97-02



**N** \*compl 503 85 24-75




**P** Accessories  
Zubehöre  
Accessoires  
Acessorios  
Tillbehör




Olja Luftfilter  
Oil Airfilter  
Öl Luftfilter  
Aceite Filtro Air  
Huile Filtraire

\*compl 503 93 42-02  
123L  
123LD




\*compl 537 18 96-01  
123C





**Q** compl 503 28 34-01

**ZAMA C1Q - EL 24**



**① 531 00 45-52**  
**Set of gaskets**  
**Dichtungssatz**  
**Juego de juntas**  
**Jeu de joints**  
**Packningssats**

**② 531 00 45-53**  
**Repairkit**  
**Reparaturatz**  
**Juego de reparación**  
**Kit de réparation**  
**Reparationsatts**

| PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER  | SQUARE NOTE | PART NUMBER | SQUARE NOTE |
|--------------|-------------|--------------|-------------|--------------|-------------|-------------|-------------|
| 501 60 02-03 | P           | 503 87 26-01 | DM          | 537 07 39-02 | E           |             |             |
| 501 78 33-01 | P           | 503 87 33-02 | H           | 537 07 68-02 | C           |             |             |
| 502 11 46-02 | P           | 503 87 35-02 | H           | 537 07 68-03 | A           |             |             |
| 502 20 38-01 | D           | 503 87 36-01 | H           | 537 08 27-01 | D           |             |             |
| 502 20 40-02 | G           | 503 87 79-01 | E           | 537 08 30-01 | D           |             |             |
| 502 20 65-03 | G           | 503 87 80-01 | E           | 537 12 78-01 | Q           |             |             |
| 502 21 58-01 | P           | 503 87 85-01 | E           | 537 18 49-01 | J           |             |             |
| 502 28 59-01 | P           | 503 87 86-01 | E           | 537 18 63-01 | G           |             |             |
| 503 20 02-10 | D           | 503 88 79-01 | G           | 537 18 96-01 | P           |             |             |
| 503 20 02-25 | M           | 503 88 80-02 | G           | 537 19 92-02 | B           |             |             |
|              |             |              |             |              |             |             |             |
| 503 20 03-25 | G           | 503 89 03-01 | G           | 537 21 45-01 | A           |             |             |
| 503 20 07-25 | BD          | 503 91 09-01 | G           | 537 21 49-01 | C           |             |             |
| 503 20 07-35 | L           | 503 91 10-01 | J           | 537 21 62-02 | P           |             |             |
| 503 20 14-12 | B           | 503 91 18-02 | J           | 537 23 49-01 | B           |             |             |
| 503 20 15-01 | B           | 503 91 81-01 | E           | 537 23 75-02 | ACM         |             |             |
| 503 20 29-50 | L           | 503 93 42-02 | P           | 537 23 96-01 | K           |             |             |
| 503 21 07-16 | P           | 503 93 66-01 | J           | 537 24 64-01 | D           |             |             |
| 503 21 66-18 | EM          | 503 94 02-01 | N           | 537 24 96-01 | K           |             |             |
| 503 21 68-20 | FHM         | 503 94 26-01 | G           | 537 28 56-01 | B           |             |             |
| 503 21 71-16 | K           | 503 96 13-02 | E           | 537 28 97-02 | M           |             |             |
|              |             |              |             |              |             |             |             |
| 503 21 75-16 | G           | 503 96 14-01 | E           | 537 29 26-01 | B           |             |             |
| 503 21 75-50 | G           | 503 96 25-01 | G           | 537 29 47-04 | CD          |             |             |
| 503 21 77-16 | H           | 503 96 49-01 | H           | 537 29 47-05 | A           |             |             |
| 503 21 83-16 | P           | 503 97 40-01 | Q           | 537 32 08-02 | F           |             |             |
| 503 21 98-35 | AC          | 503 97 43-01 | Q           | 537 33 56-02 | L           |             |             |
| 503 22 26-01 | AC          | 503 97 64-01 | P           | 537 34 25-01 | B           |             |             |
| 503 22 65-04 | G           | 503 97 75-01 | K           | 537 35 17-01 | C           |             |             |
| 503 23 51-08 | K           | 503 98 54-01 | D           | 537 35 33-01 | F           |             |             |
| 503 23 51-11 | K           | 503 99 55-01 | E           | 537 35 33-02 | F           |             |             |
| 503 25 24-01 | B           | 503 99 56-01 | E           | 537 35 33-03 | F           |             |             |
|              |             |              |             |              |             |             |             |
| 503 28 34-01 | GQ          | 530 03 85-99 | A           | 537 35 34-01 | H           |             |             |
| 503 28 90-41 | L           | 530 05 38-00 | A           | 537 35 34-02 | H           |             |             |
| 503 44 32-01 | J           | 530 09 45-43 | A           | 537 35 34-03 | H           |             |             |
| 503 47 89-01 | Q           | 531 00 45-52 | Q           | 537 37 03-01 | Q           |             |             |
| 503 47 90-01 | Q           | 531 00 45-53 | Q           | 537 37 38-01 | M           |             |             |
| 503 47 92-01 | Q           | 531 00 92-48 | P           | 725 23 70-51 | A           |             |             |
| 503 47 96-01 | Q           | 537 00 84-01 | H           | 725 23 79-51 | D           |             |             |
| 503 47 97-01 | Q           | 537 01 13-01 | E           | 731 23 14-01 | GM          |             |             |
| 503 48 00-01 | Q           | 537 01 16-01 | D           | 731 71 16-51 | HK          |             |             |
| 503 48 01-01 | Q           | 537 01 19-01 | D           | 735 31 08-20 | H           |             |             |
|              |             |              |             |              |             |             |             |
| 503 48 05-01 | Q           | 537 01 25-01 | Q           | 735 31 11-00 | B           |             |             |
| 503 48 08-01 | Q           | 537 01 26-01 | Q           | 735 31 12-00 | ACM         |             |             |
| 503 48 11-01 | Q           | 537 01 41-01 | L           | 735 31 25-10 | B           |             |             |
| 503 48 18-01 | Q           | 537 01 96-01 | Q           | 735 31 28-10 | B           |             |             |
| 503 48 19-01 | Q           | 537 01 97-01 | Q           | 735 58 08-10 | D           |             |             |
| 503 49 71-01 | G           | 537 01 98-01 | Q           | 737 44 08-00 | L           |             |             |
| 503 53 57-01 | Q           | 537 01 99-01 | Q           | 738 21 98-00 | B           |             |             |
| 503 57 76-01 | J           | 537 02 00-01 | Q           | 738 21 99-00 | B           |             |             |
| 503 66 59-01 | Q           | 537 02 01-01 | Q           | 738 21 99-02 | B           |             |             |
| 503 70 80-04 | D           | 537 02 02-01 | Q           | 740 42 06-00 | E           |             |             |
|              |             |              |             |              |             |             |             |
| 503 71 22-01 | LN          | 537 02 03-01 | Q           |              |             |             |             |
| 503 71 54-01 | D           | 537 02 04-01 | Q           |              |             |             |             |
| 503 71 82-01 | E           | 537 02 06-01 | Q           |              |             |             |             |
| 503 73 58-01 | J           | 537 02 07-01 | Q           |              |             |             |             |
| 503 75 53-01 | Q           | 537 02 08-01 | Q           |              |             |             |             |
| 503 78 52-01 | D           | 537 02 09-01 | Q           |              |             |             |             |
| 503 79 56-01 | ACD         | 537 02 10-01 | Q           |              |             |             |             |
| 503 79 88-01 | P           | 537 02 16-01 | Q           |              |             |             |             |
| 503 80 17-01 | P           | 537 03 20-06 | L           |              |             |             |             |
| 503 81 60-01 | K           | 537 03 22-01 | K           |              |             |             |             |
|              |             |              |             |              |             |             |             |
| 503 84 28-01 | K           | 537 03 94-03 | L           |              |             |             |             |
| 503 84 29-02 | K           | 537 04 11-02 | M           |              |             |             |             |
| 503 85 24-75 | N           | 537 04 24-01 | J           |              |             |             |             |
| 503 85 28-01 | H           | 537 04 25-01 | C           |              |             |             |             |
| 503 85 29-02 | E           | 537 04 67-01 | K           |              |             |             |             |
| 503 85 63-01 | B           | 537 04 68-01 | K           |              |             |             |             |
| 503 85 87-01 | H           | 537 04 89-01 | Q           |              |             |             |             |
| 503 85 89-01 | H           | 537 04 90-01 | Q           |              |             |             |             |
| 503 87 17-01 | L           | 537 06 86-04 | J           |              |             |             |             |
| 503 87 18-01 | F           | 537 07 37-01 | A           |              |             |             |             |

Set of gaskets, Dichtungssats,  
Jeu de joints, Juego de juntas,  
Packningsatts

N = New part, Neues teil,  
Nouvelle piece, Nueva pieza  
Ny detalj