





SERVICE 		3
		3SX 90.008


Clearing Saw Accessories

Freischneider Zubehöre

Débroussailleuse Accessoires

Desbrozadora Accesorios

Röjsågstillbehör






Saw blades 200 mm—8"


Maxi 200 saw blade
502 04 13-02

For min 24 cc




Scarlet 200 saw blade
501 91 34-01


For min 24 cc



**Plant protector
(complete)**
502 14 55-01




Guard
502 03 93-03



Saw blades 225 mm—9"


Maxi 225 saw blade
502 01 95-02

For min 35 cc



Scarlet 225 saw blade
501 91 35-01


For min 35 cc




Saw blades 225 mm—9"

Spets 225 pointed-tooth blade
502 14 25-01

For max 35 cc



Guard
502 03 94-03





Brush blades 255 mm—10"

Multi 255-4 brush blade
501 91 05-02
For min 24 cc

Multi 255-3 brush blade
502 17 58-01
For min 24 cc

Plant protector (complete)
502 12 26-01

Guard
502 03 95-03

Brush blades 300 mm—12"

Multi 300 brush blade
502 17 56-01
For min 35 cc

Guard
502 03 96-03

Nylon cordheads

Trimmy Fix
502 13 87-01
For max 45 cc

Trimmy H
501 91 28-03
For max 35 cc

Trimmy Hit II
502 12 65-01
For max 35 cc

Trimmy Automatic
952 70 85-29
For max 30 cc

Trimmy S
508 01 01-02
For min 35 cc

Support cup
502 15 70-01

Support cup
502 13 93-01


Guard
502 10 47-01

Nylon cords


98 m, 297 feet
 Ø 2,4 mm
 508 01 51-49




15 m, 45 feet
 Ø 2,4 mm
 502 04 77-01



60 m, 200 feet
 Ø 2,0 mm
 952 70 85-12
 (for trimmy Automatic)




Pre cut for Trimmy Fix
 20 strings
 Ø 2,4 mm
 502 13 86-01



Nylon cordheads

Trimmy H


compl 501 91 28-03



Nylon cordheads


Trimmy Hit II

* compl. 502 12 65-01



Trimmy S

* compl. 508 01 51-54



Guard

