

# BV32

Spare parts  
Ersatzteile  
Pièces détachées  
Reserve onderdelen  
Repuestos  
Reservdelar

## Note !

To identify correct part number, check trimmer type at the end of the serial number decal.

Example of serial number; 02134N401525-2

The -2 tells it is a type 2.

02 means it was build in 2002.

The 134 means it was built on the 134th day of that year.

The 401525 is the individual serial number for that particular unit.

PARTS LIST NO. 530068885 - 8/07/02	
PAGE NO. 1	REPLACES 530068885-9/13/01


# Jonsered® PARTS LIST

MODEL:  
BV32

Note: Illustrations may differ from actual models due to design changes

**⚠ WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

**TYPE 1**



Operator's  
Manual

Engine  
Gasket  
Kit

Spark  
Arrestor  
Kit

107

108

104

109

100

101

102

Key No.	Part No.	Description	<b>TYPE 1</b>	Key No.	Part No.	Description	<b>TYPE 1</b>
1	530094712	Handle		64	530019158	Crankshaft Seal	
2	530026994	Front Isolator		65	530032102	Outer Bearing	
3	530029111	Spacer - Isolator		66	530015789	Retaining Ring	
4	530015635	Screw		67	530014016	Crankcase Assy.	
5	530029130	Rear Isolator		68	530039189	Flywheel Assy.	
6	530015813	Screw		69	530347987	Washer	
7	530029072	Trigger		70	530023817	Starter Dog Spring	
8	530037595	Assist Handle Ass'y		71	★	Spacer- <b>See Service Ref. 3</b>	
9	530029228	Spark Arrestor Clamp		72	530014156	Crankcase/Crankshaft Assy.	
10	530029988	Exhaust Deflector Ass'y.		73	530016080	Screw	
11	530015840	Pin - Handle		74	530015496	Screw	
12	534790500	Nut		75	530027523	Retainer	
13	530037864	Shroud-Right		76	★	Starter Pulley (Incl.73) - <b>See Service Ref. 1</b>	
14	530037934	Shroud-Left					
16	530069572	Switch Kit		77 ✓	530042085	Starter Spring	
17	530029129	Isolator - Engine Mount		78	530069714	Fan Housing Kit (Incl. 71, 73-77, 79, 82-84, 86 & 105)	
18	530029295	Isolator - Tank					
19	530015814	Screw		79	530027569	Starter Handle	
20	530014162	Fuel Tank Ass'y. (Incl. #21, 22 & 106)		80	530029117	Throttle Lock Button	
21	530014347	Fuel Cap (w/ retainer)		81	530015769	Screw	
22 ✓	530095646	Fuel Pick-up Ass'y.		82	★	Bearing- <b>See Service Ref. 3</b>	
23	530014160	Handle Cover Assy.		83	★	Spacer- <b>See Service Ref. 3</b>	
24	530037865	Filter Cover		84	★	Screw- <b>See Service Ref. 3</b>	
25	530029112	Air Filter		85	530019167	"O" Ring	
26	530029404	Air Baffle		86	530029182	Eyelet	
27	530069293	Muffler Kit		87	530029227	Spark Arrestor Screen	
28	530029116	Muffler Spring		88	530015702	"C" Clip	
29	952030201	Spark Plug (RCJ-8Y)		89	530029119	Rope Retainer Tube (Roll Pin)	
30	530001624	Screw		90	530094710	Blower Housing (Upper)	
31	530069628	Cylinder Kit		91	530029173	Band	
32	530029145	Lead Wire Assy.		92 ✓	530047077	Impeller (Includes Hub)	
33	530039137	Ignition Module		93	530014339	Deflector & Clamp Ass'y.	
34	530015816	Screw		94	530015818	Washer - Impeller	
35	530019178	Cylinder Gasket		95	530015441	Washer	
36	530025875	Piston Ring		96	530001733	Nut	
37	530069277	Piston Kit (Incl. #36,38, & Pin)		97	530047736	Blower Housing (Lower) (Incl. 100-103 & door)	
38	530015162	Wrist Pin Retainer		98	530024772	Spring - Throttle	
39	530015306	Screw		99	530027597	Spring - Lever Return	
40	530029144	Ground Wire Assy.		100	530015667	Spring - Torsion (right)	
41	530015849	Screw		101	530015647	Pin - Pivot	
42	530015254	Wave Washer		102	530015815	Screw	
43	530015852	Choke Spacer		103	530015672	Spring - Torsion (left)	
44	530029114	Choke Shutter		104	530069348	Spark Arrestor Kit	
45	530015775	Screw		105	530069232	Rope Kit	
46	530037492	Cable Assembly		106	530069247	Kit - Line Carb./Purge	
47	530029115	Air Filter Plate		107		Operator's Manual	
48	530069644	Carburetor Kit (WT 141A w/ Limiter Cap)			530083432	Scandinavian	
49	530019164	Carb. Gasket			530083433	European	
50	530019165	Foam Seal		108	530069294	Gasket Kit (Incl. 35, 49, 50 & 54)	
51	530015771	Screw		109 ✓	530015814	Screw	
52	530029113	Ground Wire		110	★	Inlet Door- <b>See Service Ref. 4</b>	
53	530047696	Reed Block / Heat Shield		111	530049185	Air Dam Sponge	
54	530019166	Gasket		112 ✓	530053346	Heat Shield / Air Dam	
55	530027593	Reed Valve		113	530019168	Grommet-Carb. Box	
56	530027594	Reed Stop		114	530019253	Seal Foam	
57	530016064	Screw					
58	530014033	Crankshaft- <b>See Service Ref. 2</b>					
59	530015126	Flywheel Key					
60	530010960	Connecting Rod Ass'y.			Not Shown		
61	★	Spacer- <b>See Service Ref. 2</b>					
62	530032103	Inner Bearing			530047885	Decal-Door Instruction	
63	530015787	Retaining Ring					

✓ =PART NUMBER CHANGE

★ =REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION.(LOCATED AT END OF IPL)

PARTS LIST NO. 530068885 - 8/07/02	
PAGE NO. 3	REPLACES 530068885-9/13/01


# Jonsered® PARTS LIST

MODEL:  
BV32


Note: Illustrations may differ from actual models due to design changes

**WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.


**TYPE 2**








KEY NO.	PART NO.	DESCRIPTION
1	530095116	Collection Bag W/Strap
2	530095117	Collection Bag Elbow Tube
3	530069270	Vacuum Tube Ass'y
4	530038508	Tube and Nozzle Ass'y




### Carburetor Assembly

#### WT-141



Key No.	Part No.	Description
1	530035014	*+ Metering Diaphragm
2	530035151	*+ Metering Diaphragm Gasket
3	530035016	* Metering Lever Pin Screw
4	530035268	Mixture Needle
5	530035293	Mixture Needle Spring
8	530035166	*+ Fuel Pump Diaphragm
9	530035164	*+ Fuel Pump Gasket
10	530035203	Idle Speed Screw
11	530035121	Idle Speed Spring
12	530035028	* Metering Lever Pin
13	530035031	* Metering Lever
14	530035188	* Metering Lever Spring
15	530035106	* Inlet Needle Valve
16	530035178	* Fuel Inlet Screen
17	530035264	Carb. Kwik Repair Kit (*Indicates Contents)
18	530069844	Carb. Gasket/Diaphragm Kit (*Indicates Contents)

#### WT-141A #530069644




Ref.	Part No.	Description
1.	530035264	Kit - Carburetor Repair (KIT = Indicates Contents)
2.	530038403	Limiter Cap
3.	530069844	Kit - Gasket/Diaphragm

↗ =PART NUMBER CHANGE      ★ =REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION.(LOCATED AT END OF IPL)

PARTS LIST NO. 530068885 - 8/07/02		<b>Jonsered</b> ® PARTS LIST	MODEL: BV32
PAGE NO. 6	REPLACES 530068885-9/13/01		

**★SERVICE REFERENCE**


**1. Starter Pulley** - When ordering a new starter pulley for your unit, please measure your existing pulley as shown by the dimensions in the illustrations below and order accordingly.



**2. Crankshaft Spacer** - Earlier models equipped with the laminated crankshaft (shown on the left) requires Spacer 530015788. Later models equipped with a step on the crankshaft (shown on the right), do not require the spacer.



**3. Fan Housing Kit, Spacers, Bearing and Screws** - The earlier fan housing was equipped with bearing (530032108), screws (530015805) and required two spacers (530029176 and 530029110) as shown below. The new fan housing does not require a bearing and uses one long spacer (530038386). Both sets of parts are included in the new fan housing kit 530069714.



**4. Inlet Door** - The latch on the lower blower housing and door has changed. The new style can be identified by the tab found at the top of the latch on the door and the latch prongs on the housing as shown below. To replace the old door, order Lower Blower Fan Housing 530047736. To replace the door equipped on the new style housing, order 530047700.

