



SB, Front Rider, Belt guide, 2007-05

Location no. on the machine 1-4	Part no. printed on the belt	Pre packed no.	Model	Belt location on the Rider
1	506 54 49-01	531 01 31-45	FR 2111 FR 2111M	Gearbox - Engine
1	506 98 83-01	531 00 80-36	FR 2113MA FR 2113MA 4X4 FR 2116MA FR 2116MA 4X4 FR 2116MA2	Hydrostat - Engine
2	506 67 50-01	531 01 31-44	FR 2111	Engine – Cutting Deck Rear 85
2	506 76 84-01	531 00 80-35	FR 2113MA FR 2113MA 4X4 FR 2116MA FR 2116MA 4X4 FR 2116MA2	Engine – Intermediate pulley
3	506 76 85-01	531 00 80-69	FR 2116MA FR 2116MA 4X4 FR 2116MA2	Intermediate pulley – Brush
3	544 23 89-01		FR 2111M FR 2113MA	Intermediate pulley – Cutting Deck C 94
3	544 06 82-01		FR 2113MA 4X4	Intermediate pulley – Cutting Deck C 94
3	535 41 19-01	531 00 88-05	FR 2116MA FR 2116MA 4X4 FR 2116MA2	Intermediate pulley – Cutting Deck C 94XP C 103 C 103XP C 112 C 112XP
4	506 66 04-01	531 01 31-46	FR 2111	Cutting Deck Rear 85
4	544 06 81-01	544 30 64-0	FR 2111M FR 2113MA FR 2113MA 4X4	Cutting Deck C 94
4	506 76 85-01	531 00 80-69	FR 2116MA FR 2116MA 4X4 FR 2116MA2	Cutting Deck C 103
4	535 41 19-01	531 00 88-05	FR 2116MA FR 2116MA 4X4 FR 2116MA2	Cutting Deck C 112