



NOTES 11
 4 FLAT WASHERS TO BE USED
 WHEN END PLAY IS PRESENT
 ON AXLE. USE ONLY 2 FLAT WASHERS
 (ONE EACH SIDE) AGAINST THE GEAR HUB.
 WHEN ASSEMBLY IS TIGHT WITH 4 WASHERS.

E3-08457A-01